



Club de voile Senneville Yacht Club

PUMPOUT OPERATING INSTRUCTIONS

WARNINGS:

- Do NOT pump gasoline or flammable liquids. It could cause a pump fire and is a safety risk.
- Do NOT pump mud, stones or dirt
- Make sure the holding tank you are pumping has a PROPER AIR VENT. Pumping liquids out of non-vented or inadequately vented tanks can cause your tank to collapse. Always ensure that the vent line is open and free of any debris before pumping.

RECOMMENDATIONS:

- We recommend the use of RV holding tank treatment liquid in your tank, which breaks down solids and makes pumping easier.
- We recommend the use of septic tank toilet paper, which decomposes fast to allow easy pumping, OR throw out toilet paper in a garbage bag rather than in the toilet.

INSTRUCTIONS:

1. Check that the "PUMP READY" light is on.
 - a. If the "DISCHARGING" light is on, wait for the "PUMP READY" light before pushing START.
 - b. If the "PROBE ERROR" light is on, notify André Guerin, Guy La Rochelle or JF Gagnon.
2. Once you see "PUMP READY", press the START pushbutton. This enables the suction mode as indicated by the "VACUUM SUCTION" light. Wait about 1 minute to ensure there is enough vacuum buildup.
3. Open the tank screw cap from the WASTE outlet on your boat
4. Connect the correct size deck fitting to the WASTE hole on your boat, or use the universal rubber gasket tip on the suction hose.
5. Slowly squeeze and hold the trigger of the suction nozzle. If you are using the universal rubber gasket tip, make sure to keep good contact with the WASTE hole on the boat deck (you need to apply a continuous downward pressure for this).
6. Continue to empty the tank. You will see that it is empty by checking the material flow in the clear section of the suction hose.
7. When the tank is empty, let go of the trigger, and lift the hose carefully (there may be a bit of material left in the hose past the squeeze trigger, which could leak back on your deck).
8. Remove the deck fitting from the WASTE outlet if you have used one, and return it to the pumpout stand.
9. Press the STOP pushbutton and coil the hose back on its stand.

NOTE: You may hear that the pump is still working after this. This is normal, as it automatically discharges the removed material into our club's septic system.